



Wild West 2-6-0 Steam Locomotive



Metal sheets

Parts that are in the same color are duplicates

A 103, 79, 125, 35, 15, 65, 56, 68, 61, 73, 109, 32, 26, 51, 24, 36, 39, 23, 43, 70, 21, 27, 62, 89

B 86, 7, 101, 67, 29, 102, 110, 11, 37, 72, 17, 1, 16, 23, 2, 102, 3, 34, 50

C 53, 32, 119, 123, 66, 38, 6, 18, 81, 117, 120, 8, 75, 69, 98, 91, 114, 80, 54, 14, 33, 31, 88, 84, 105, 64, 99, 41, 49, 76, 40, 9, 112, 60, 44, 57, 124, 12, 19, 20, 55, 22, 48

D 111, 87, 10, 96, 96, 23, 77, 107, 30, 83, 102, 92, 4, 74, 46, 52, 118, 100, 121, 94

! In order to avoid possible injury from sharp edges, please carefully discard the metal sheets after parts have been removed

Legends:

- E** Engraved/Color side
- NE** Non-engraved/Silver side
- Hand icon** Attention point
- Blue circle** Insert tab and bend 90 degrees
- Green triangle** Insert tab and twist 90 degrees

Assembly tip:
If needed, slightly twist tabs to hold parts together then untwist and bend them down for a nice finish

Recommended tools:

- Wire cutters: helpful for taking parts from the metal sheets.
- Tweezers or needle nose pliers: helpful for folding parts, bending and twisting tabs.

Assembly Flow Chart

B-1 → **C-5** → **C-6** → **B-2** (x2) → **B-3** → **D-4** (x3) → **B-7** → **C-5** → **C-9** → **B-3** → **B-2** (x2) → **C-8** (x3) → **D-10** → **B-11** → **C-12**





