

3DPUZZLES.IT

Disney • PIXAR

WALL • E

JUNE 27



Insertion tabs are inserted and then folded.



Make sure pieces are tight to assemble.



To create the best connections

Insert tab and bend 90 degrees to meet visible circle



Insert tab and fold 90 degrees to bend in some areas to ensure a tight connection




⚠ In order to avoid possible injury from sharp edges, please carefully discard the metal sheet after parts have been removed




step3




step4



step5




step6



step7


step8

step9




step6

step7




step8

step4





step1




X2

step2







step10




step11



step12



step13



step2